



Acer Aspire E5-571 Battery Replacement

How to remove and replace the battery.

Written By: daniel sawyer



INTRODUCTION

Can't seem to charge your battery? It may be time to replace it. This guide will walk you through the simple steps to access and replace your battery.



TOOLS:

- [Small Phillips Head Screwdriver](#) (1)
-

Step 1 — Battery




- ⚠ Make sure the laptop is shut down.
- Flip the laptop upside down with the battery facing towards your body and locate the battery lock circled in red.

Step 2



- Use a small screwdriver or pen and place it into the battery lock as shown.
- Gently slide it to the left until you hear the battery release.

Step 3



- Pull the battery towards your body as shown in the picture.

To reassemble your device, follow these instructions in reverse order.

This document was last generated on 2017-06-29 05:40:15 PM.